



# Strut for FLST models

BIG TWIN



**FXST Models**

50-1070	Replica	1986-99
50-1069	Smooth	1986-99
50-2019	OE	2000-05
50-2040	Replica	2000-05

50-2039	Smooth	2000-05
50-0649	Replica	2006-07
50-0651	Smooth	2006-07

**FLSTF**

50-1071	Replica	1986-99
50-0598	OE	1986-99
50-2042	Replica	2000-02
50-1102	OE	2000-02
50-1208	Replica	2003-07
50-0887	Replica	2008-up
50-0861	Inner Strut	2008-up



Rear Fender Strut Cover Trim fits 06-up FXST, 07-up FXSTC.  
VT No. 50-0110

**FLST Models**

50-1071	Replica	1986-99
50-0598	OE	1986-99
50-1211	Replica	2000-02
50-1212	Replica	2003-06
50-0649	Replica	2007
50-0862	Replica	2008-up
50-0863	As Above	Smooth
50-0865	Replica Inner Strut	2008-up

# Strut Bolt Set



Chrome Allen Fender Strut Bolt Kits include necessary allen head bolts, washers & nuts for fender mounting.

VT No.	Year	Model
37-8978	1986-99	FXST
9920-46	1986-99	ST (4 hole Strut)
9921-56	1986-99	(6 hole Strut)
2044-26	2000-up	ST models
2043-26	2000-up	ST models (Low Profile)



Chrome Rear Fender Support Mount Kit to replace original hardware.

VT No.	Year/Model	Style
37-0542	1986-99 FXST, FLST	Stock
37-8978	1986-99 FXST	Allen
2045-34	2000-06 ST	Acorn
2290-14	2007-up ST	Allen



1986-99 FXST Fender Strut Mount Kit includes chrome socket bolts, special nuts, washers and pasties chrome covers to match cylinder head bolt dome covers. VT No. 37-8907



9920-46



9921-56

Rear Fender Strut Chrome Mounting Kit are unique low profile allen hardware kits to mount struts to fender.

VT No.	Item
9920-46	Mount 4 hole struts on 1986-99 5-speed Heritage Softail and Fat Boy, pictured.
9921-56	Mounts 6 hole struts on 1986-99 FXST, FXSTC, FXSTS and Bad Boy.
2043-26	FX & FL Softail 2000-up except FX Deuce